

Thule WingBar Edge Technical Specifications

THULE WINGBAR EDGE RAISED RAIL		Absolute Bar Length	(X) Bar Spacing Min/Max Mounting width for products		(Y) Foot Spacing Min/Max Mounting width on vehicle	
Part #	Description	(Bar only. No feet) mm	Min. mm	Max. mm	Min. mm	Max. mm
9581	Raised Rail Small	752	630	730	840	940
9582	Raised Rail Medium	832	680	810	920	1020
9583	Raised Rail Large	912	790	890	1000	1100
9584	Raised Rail Small + Medium	See measures above, 9581 + 9582				
9585	Raised Rail Medium + Large	See measures above, 9582 + 9583				

NOTE: Y measurements are from inside to inside of vehicle's raised rail.



THULE WINGBAR EDGE FIXED & FLUSH		Absolute Bar Length	(X) Bar Spacing Min/Max Mounting width for products		(Y) Foot Spacing Min/Max Mounting width on vehicle	
Part #	Description	(Bar only. No feet) mm	Min. mm	Max. mm	Min. mm	Max. mm
9591	Fixed/Flush Small	816	694	794	909	1009
9592	Fixed/Flush Medium	896	744	874	989	1089
9593	Fixed/Flush Large	976	854	954	1069	1169
-	Fixed/Flush XL	1076	954	1054	1169	1269
9594	Fixed/Flush Small + Medium	See measures above, 9591 + 9592				
9595	Fixed/Flush Medium + Large	See measures above, 9592 + 9593				
9596	Fixed/Flush Large + XL	See measures above, 9593 + Fixed/Flush XL (not sold separately)				

NOTE: Y measurements are center to center of vehicle's fixed point, flush rail or track.

